

# Installation Instructions

## Fits $\frac{3}{4}$ " to $\frac{7}{8}$ " Thickness

### Step 1

Drill  $\frac{7}{8}$ " hole from front to inside. Location should be  $\frac{3}{4}$ " from edge. (See illustration No. 1.)

### Step 2

Mortise  $1\frac{1}{4}$ " x  $1\frac{1}{4}$ ". Depth should be sufficient to allow lock to be flush with outside surface. (See illustration No. 2.)

### Step 3

Push lock through from inside and mount with screws provided. (See illustration No. 3.)

### Step 4

Strike enclosed is optional. On some installations strike may not be required.

## Wright Products

Rice Lake, Wisconsin 54868 U.S.A.

