

Installation Instructions

Step 1

This set is reversible for right or left hand application. The inside handle assembly should be placed on the door with the hand grip toward the glass. The latch must rotate upward, if it is necessary to change the latch rotation remove the thumb turn, rotate 1/2 turn and reassemble.

Wright Products

Rice Lake, Wisconsin 54868 U.S.A.

Step 2

Attach the inside handle assembly and outside handle together on door with the machine screws provided.

98387-00 Rev. A

Step 3

Attach the latch keeper to your door jamb and align so the keeper engages the latch. If you have a keeper presently installed, loosen the screws and adjust as necessary.

